

RFI Suppression Kit






www.westmountainradio.com

1020 Spring City Drive Waukesha, WI 53186 262-522-6503 sales@westmountainradio.com

©2018 West Mountain Radio, All rights reserved. All trademarks are the property of their respective owners.

An example of a cable wound through and around a ferrite toroidal core.



INTRODUCTION

Thank you for choosing the **RFI Suppression Kit** that was created as an inexpensive remedy for many types of issues encountered when excessive RF is getting back into the shack.

One may not even be aware of an RFI (Radio Frequency Interference) problems that subsequently attribute effects to other causes. For example: The computer, mouse, or digital mode interface which becomes non-responsive could easily be a software problem; but, it could be RFI as well. Another example of too much RFI in a shack is when the radio shuts down unexpectedly when transmitting at full-power.

Many of these problems can be resolved with judicious use of filters like the toroidal cores and snap on chokes supplied in the RFI Suppression Kit. The table below provides some ideas on possible remedies to situations. This kit does not provide any guarantees of eliminating all RFI problems, but may provide a better chance.

INSTALLATION and USAGE

Included in the RFI Suppression Kit:

- · 3 toroidal cores*
 - 2 are type 43 ferrite material (useful at higher HF bands, VHF & UHF)
 - 1 is type 31 material (very effective throughout the HF spectrum)
- 2 snap-on type 31 chokes which can be easily placed around cables or coax.

Some antennas are more likely to bring high levels of RF into the shack. End-fed "long wires" with a manual tuner close to the radio is one example. The feed point impedance is often very high which means large HF voltages at the tuner. In cases like this, it is often better to feed the "long wire" with an 9:1 balun mounted outside and run coax into the shack from the balun to the tuner. Adding some of the snap-on chokes on this coax may help to keep RF out.

When winding cables through the toroid the more turns the better. Use a cable tie to anchor the cable at one end then proceed to wind the cable through the toroid. Use another cable tie to anchor the other end.

- * A quick way to tell the toroids apart is to use your DMM on the resistance setting. Put your probes on the side of the toroid about 1cm apart. Type 31 will have a much lower measurable resistance depending on your probe spacing and pressure (typically 200KOhm 1MOhm). Type 43 will likely not register on your meter as the electrical resistance is much higher.
- * The ARRL maintains a very useful web page with articles and web links dealing with RFI.

Radio locks up or shuts down when into your PSU or radio transmitting SSB/FM power cable. Voice at full power. Computer or peripherals (e.g. mouse, keyboard) stop working/become radio transmits. Radio gets stuck RF is getting into the ransmission of uransmission during digital mode during digital mode operation and can can can can be computer or or the computer or or the computer or or the computer or the computer or digital or transmission in transmission the computer or digital or the computer or digital or the computer or digital interface and crashing cord and/or or laptop operation and can the computer or digital or the computer or digital interface. Radio gets stuck RF is getting into the through the type 31 through a typeral or the computer or digital or the	Symptom	Possible Explanation	HF Remedy	VHF Remedy	Other Ideas
into your PSU or radio on the PSU AC cord. power cable. Try winding the radio power cable through the type 31 toroid. RF is getting into Try a snap-on choke adapter cord. Try winding affected peripheral cable through the type 31 toroid. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. Dus. Try winding the digital interface USB cable through the type 31 toroid.	Radio locks up or	RF could be getting	Try a snap-on choke	Wind the PSU AC	Try reducing power
Try winding the radio power cable through the type 31 toroid. RF is getting into peripheral. RF is getting into the computer AC cord and/or or laptop adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.	shuts down when	into your PSU or radio	on the PSU AC cord.	cord through a type 43	and/or try a dummy
RF is getting into peripheral. RF is getting into peripheral. RF is getting into the computer AC cord and/or or laptop adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop adapter cord. Try winding the digital interface and crashing adapter cord. Try winding the digital interface USB cable through the type 31 toroid.	transmitting SSB/FM	power cable.		toroid.	antenna to prove it is
RF is getting into the computer AC peripheral. RF is getting into the computer AC cord and/or or laptop adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop adapter cord. BE is getting into the computer AC interface and crashing cord and/or or laptop adapter cord. Bus. Try winding the digital interface USB cable through the type 31 toroid.	voice at full power.		Try winding the radio		an RF issue.
RF is getting into RF is getting into RF is getting into the computer AC peripheral. Try a snap-on choke on the computer AC cord and/or or laptop adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.			power cable through	Try winding the radio	
RF is getting into RF is getting into the computer AC cord and/or or laptop adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop the computer's usb bus. Try winding the digital interface USB cable through the type 31 toroid.			the type 31 toroid.	power cable through a	
RF is getting into the computer AC peripheral. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing adapter cord. Try winding affected peripheral cable through the type 31 toroid. Try winding the digital on the computer AC interface and crashing adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.				type 43 toroid.	
the computer or on the computer AC peripheral. n Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. Try winding the digital interface USB cable through the type 31 toroid. Try winding the digital interface USB cable through the type 31 toroid.	Computer or	RF is getting into	Try a snap-on choke	Wind the computer AC	Try reducing power
me adapter cord. Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop the computer's usb bus. Try winding the digital interface USB cable through the type 31 toroid.	peripherals (e.g.	the computer or	on the computer AC	cord or laptop adapter	and/or try a dummy
RF is getting into the computer or digital interface and crashing the computer s usb bus. Try winding affected peripheral cable through the type 31 toroid. Try a snap-on choke on the computer AC interface and crashing cord and/or or laptop adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.	mouse, keyboard)	peripheral.	cord and/or or laptop	cord through a type 43	antenna to prove it is
Try winding affected peripheral cable through the type 31 toroid. RF is getting into the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.	stop working/become		adapter cord.	toroid.	an RF issue.
RF is getting into the computer or digital interface and crashing the computer susb bus. Try winding affected peripheral cable through the type 31 toroid. Try winding the digital adapter cord. Dus. Try winding the digital interface USB cable through the type 31 toroid.	unresponsive when				
RF is getting into the computer or digital computer or digital on the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. Try winding the digital interface USB cable through the type 31 toroid.	radio transmits.		Try winding affected	Try winding affected	Moving the computer
RF is getting into the computer or digital computer or digital on the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. Try winding the digital interface USB cable through the type 31 toroid.			peripheral cable	peripheral cable	and/or peripheral
RF is getting into the computer or digital computer or digital on the computer AC interface and crashing the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.			through the type 31	through a type 43	further from the radio,
RF is getting into the computer or digital on the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.			toroid.	toroid.	tuner or linear amplifier
RF is getting into the computer or digital on the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.					may help.
computer or digital on the computer AC interface and crashing cord and/or or laptop the computer's usb adapter cord. Try winding the digital interface USB cable through the type 31 toroid.	Radio gets stuck	RF is getting into the	Try a snap-on choke	Wind the computer AC	Try reducing power
interface and crashing cord and/or or laptop the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.	in transmission	computer or digital	on the computer AC	cord or laptop adapter	and/or try a dummy
the computer's usb adapter cord. bus. Try winding the digital interface USB cable through the type 31 toroid.	during digital mode	interface and crashing	cord and/or or laptop	cord through a type 43	antenna to prove it is
	operation and can	the computer's usb	adapter cord.	toroid.	an RF issue.
	by unplugging the		Try winding the digital		Moving the computer
	interface		interface LISB cable		and/or digital mode
toroid.			through the type 31		interface further from
torold.			tilloagii tile type of		HIGH ace laither Home
			toroid.		the radio, tuner or
					linear amplifier may
					help.

Others report "RF" in your signal	RF may be coupling back into the radio microphone or radio	Try winding the radio power cable through the type 31 toroid.	Try winding the radio power cable through the type 43 toroid.	Moving the radio further away from a linear amplifier or tuner
	itself.	Try adding one of the	Try adding one of the	may help.
		snap-on chokes to the	snap-on chokes to the	Placing a manual tuner
		microphone cable.	microphone cable.	on top of the radio is
				usually not a good
				Idea.
Other household	RF may be coupling	Try winding affected	Try winding affected	Quite often the
equipment	back into AC house	device power cords	device power cords	proximity of your ham
malfunctions when	wiring, telephone line	through the type 31	through the type 43	radio antenna is to
operating your	wiring or domestic	toroid.	toroid.	blame when other
ham radio e.g. TV,	antenna wiring.			devices malfunction.
Telephone, HiFi		Use a snap-on choke	Use a snap-on choke	Try to ensure your
		with multiple turns of	with multiple turns of	antenna is far from the
		telephone line through	telephone line through	electrical house wiring,
		نب	ij	telephone wiring as
				possible.
				Vertical antennas are
				more likely to interfere
				with house wiring.



RFI Suppression Kit Warranty

RFI Suppression Kit is warranted against failure due to defects in workmanship or materials for 30 days after the date of purchase from West Mountain Radio. Warranty does not cover damage caused by abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation, alteration, lightning, or other incidence of excessive voltage or current. If failure occurs within this period, return the *RFI Suppression Kit* or accessory to West Mountain Radio at your shipping expense. The device or accessory will be repaired or replaced, at our option, without charge, and returned to you at our shipping expense. Repaired or replaced items are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the *Epic PWRgate* or accessory made after the expiration of the warranty period.

West Mountain Radio shall have no liability or responsibility to customer or any other person or entity with respect to any liability, loss, or damage caused directly or indirectly by use or performance of the products or arising out of any breach of this warranty, including, but not limited to, any damages resulting from inconvenience, loss of time, data, property, revenue, or profit, or any indirect, special incidental, or consequential damages, even if West Mountain Radio has been advised of such damages.

Except as provided herein, West Mountain Radio makes no express warranties and any implied warranties, including fitness for a particular purpose, are limited in duration to the stated duration provided herein.



www.westmountainradio.com 1020 Spring City Drive, Waukesha, WI 53186 tel 262-522-6503 fax 262-522-6504