

***RI**Grunner*

for model

8012



www.westmountainradio.com

1020 Spring City Drive
Waukesha, WI 53186
262-522-6503

sales@westmountainradio.com

©2015 West Mountain Radio, All rights reserved.
All trademarks are the property of their respective
owners.

Thank you for choosing the West Mountain Radio RIGrunner 8012. You will enjoy having a RIGrunner with durable, standardized Powerpole® connections. Having proper DC distribution should make a long overdue improvement to the convenience and safety of your station. The RIGrunner is a simple device, with obvious function. Think of a RIGrunner as the 12 volt equivalent of a 120 VAC power panel in a house.

There are some considerations to think about. Please read these instructions carefully before setting up your RIGrunner.

Choosing a mounting location

Pick a location that is close, or central to, most of your radios and accessories; especially those that draw large amounts of current. Locate your power source as close as possible to the RIGrunner. The RIGrunner 8012 comes equipped with 6 feet of 8 AWG stranded wire terminated with 1/4 inch ring terminals. This should be sufficient for most installations.

Install in a cool dry place with good ventilation. For example, do not put it on top of your amplifier or room heater, or cover it with something. It is recommended to not put it in the engine compartment of your car, or directly on the floor of a car; rain from open windows or snow covered boots may cause water damage.

Connecting your equipment

Recognizing that RIGrunner comes standard with Powerpole®, updating your cables that supply or use 12 volts DC with Powerpole® connectors will improve the convenience of quick connections and use of your equipment. Remember, Powerpole® connectors are genderless and the same connector arrangement works for both supply and load. Powerpole® connectors can be used to charge or power batteries, all using the same connectors.

Powerpole® connectors can be installed by soldering or crimping. Be sure to make good connections. For detailed Powerpole® connector installation tips see RIGrunner support pages at <http://www.westmountainradio.com/content.php?page=supportrr>

IMPORTANT!! It is essential that assembly of the pairs is correct. Follow the amateur radio standard used by the RIGrunner. **DO NOT PLUG IN** without verifying that **RED + PLUS** and **BLACK – MINUS** is correct.

This RIGrunner has one input wire that feeds two output sections: A and B. Each section, protected by its 40 amp fuse, has six fused outputs. The largest fuse is closest to the center, 1A and 1B, with progressively lower value fuses towards both ends, 6A and 6B. This arrangement allows 80 amps input and a maximum of 40 amps in each section. The input wire attached to the 8012 should be securely connected to the 12V power supply. This wire connects centrally within the RIGrunner at the junction of both input fuses.

Anderson Power Products® and Powerpole® is a registered trademark of Anderson Power Products, Inc.

Before plugging in all equipment, divide the equipment so that the power drain would be similar between both sections. For instance, if using two 100 watt radios, plug one in position 1A and the other in position 1B. Continue to divide the loads similarly for the lower power devices. Typically, 12V amplifiers and 100 watt transceivers would use a 25 amp fuse. VHF radios, transverters and other accessories would use lower value fuses.

Using the proper fuses

The RIGrunner 8012 comes supplied with a range of fuses installed. This assortment should be suitable for most stations, but can be changed easily. Every RIGrunner output is safe up to 80 amps, but the total allowable is also 80 amps.

A fuse **MUST** have be in each position in use. **ANY ATTEMPT TO BYPASS OR SHORT ACROSS THE FUSES IS DANGEROUS AND VOIDS THE RIGRUNNER WARRANTY.** Since the maximum available automotive fuse is 40 amps, the RIGrunner will be protected as long as any value ATC/ATO fuse is installed. Choose the correct fuse for your equipment. Standard ATC/ATO automotive blade fuses are used. These fuses are available in 10 values ranging from 1 amp to 40 amps.

The DC input should have a fuse that is appropriate for the power supply rating. If using a smaller power supply, consider using a lower value fuse than the 40 amp value supplied. Ideally all of the outlets should have a fuse that is the next higher value above the maximum current draw of the unit on that fuse. If using a power cord with a fuse, match that value or go one or two values higher. Sizing each fuse for each unit is desirable, but not absolutely necessary. Having a higher value than the minimum will offer less protection for that unit, too low a value and the fuse will blow out prematurely.

Note that each fuse position has a LED blown fuse indicator that will conveniently light up if an output fuse is blown. There must be power to the RIGrunner and a load on the circuit that has the blown fuse for the blown fuse LED to light.

The voltage comparator and audible alert

A feature of the RIGrunner 8012 is the precision expanded scale voltage comparator display with audible alert. A basic explanation of 12 volt systems will aid in understanding this feature. Equipment commonly referred to as 12 volt is actually a nominal 13.8 volts. For example, a lead acid battery is a nominal 12.6 volts when charged and not under load, and approximately 14.0 volts under charge. A quality 12 volt power supply will have its regulated output set to 13.8 volts. Most radios are specified to require 13.8 volts +/- 15%. 12 volt automobile or aircraft alternators have voltage regulation set between 13.5 and 14.3 volts.

Provided is an accurate and very unambiguous display of your voltage, taking into account all of the above. There are three LEDs: red overvoltage, green normal, and yellow undervoltage. The points at which the LEDs change are set accurately to 11.5 and 15.0 volts. The selection of these points gives a reliable indication of proper and safe operation of your power supply, battery or alternator. A green or normal indication is all you need to look for.

An undervoltage indication, shown by the yellow LED, is less than 11.5 volts. This should be safe for your radio, but may cause improper operation. Low voltage on a modern radio can cause a loss of phase lock and a frequency error. This is a definite indication of a problem with the power source; a bad connection, an unregulated power supply, a bad alternator or dying battery. It is normal with most cars to have less than 11.5 volts when cranking the starter motor.

A normal indication with the green LED illustrates, everything is good and you are between 11.5 and 15.0 volts, don't worry about a thing.

A red overvoltage indication with the red LED is a warning, DISCONNECT OR TURN OFF YOUR POWER SUPPLY IMMEDIATELY! It is possible to overheat or damage a radio or other equipment. An overvoltage will sound an audible alert; no need to watch the LEDs to signal a problem.

The audible alert may be configured for only undervoltage or only overvoltage, or may be disabled altogether. Simply place the P14 jumpers on under, over, both or none. Store the unused jumpers for later use.

Note: Due to the characteristics of the comparator chip it is normal for the undervoltage LED to glow very dimly with a normal or overvoltage indication. It is also normal for the LEDs to change intensity while stepping through 10 precision points.

In the event of a bad power source or power connection, the yellow LED may flash or come on during transmit. If this happens, check the power source and connections. It is also possible for RF from a transmitter to cause an electronically regulated power supply to lose regulation and cause an overvoltage alert during transmit. The RIGrunner is extensively RF bypassed and should actually cure this problem. If you do have an overvoltage condition during transmit especially with a VHF high power amp, it is due to inadequate RF filtering on the DC lead of the amplifier, or poor RF immunity of the power supply regulator circuit.

ADDITIONAL RESOURCES

Go to our support page for more assistance:

**[http://www.westmountainradio.com/
supportrr.htm](http://www.westmountainradio.com/supportrr.htm)**

Go to our OpTips page for connection tips:

**[http://www.westmountainradio.com/
optipsrr.htm](http://www.westmountainradio.com/optipsrr.htm)**

RIGrunner Accessories

Order Sku#

Fuse Assortment Low Value (8pcs) 3- 1A, 3- 5A & 2- 10A	#58537-1085
Fuse Assortment High Value (8pcs) 2 ea. of 15A, 20A, 30A, 40A	#58537-1086
Buss 10A ATC Circuit Breaker	#58537-1087
Buss 15A ATC Circuit Breaker	#58537-1088
Buss 20A ATC Circuit Breaker	#58537-1089
Buss 25A ATC Circuit Breaker	#58537-1090
Buss 30A ATC Circuit Breaker	#58537-1091
Powerpole® Extension Cable, 3 ft. #12 Red/Black Wire w/ Powerpole® ends	#58531-1082
Powerpole® Extension Cable, 6 ft. #12 Red/Black Wire w/ Powerpole® ends	#58531-1083
Powerpole® Extension Cable, 10 ft. #12 Red/Black Wire w/ Powerpole® ends	#58531-1084
15A. Powerpole® Connector-12 Pair	#58257-1093
30A. Powerpole® Connector-12 Pair	#58257-1095
45A. Powerpole® Connector-12 Pair	#58257-1099
Powerpole® Retention Clips - 12 Pack	#58257-1092
PowerLock - RIGrunner Retainer Kit	#58512-1060
PWRcrimp Crimp Tool	#58568-1049

*To purchase or view other accessories available,
call or go online at:
www.westmountainradio.com/shop*

Powerpole® Wiring Guide

Powerpole® Series Contact	Recommended Wire Gauge
15 A	20-16 AWG
30A	20-12 AWG
45A	14-10 AWG

*Additional Resources for Anderson Powerpole®s
go to: www.andersonpower.com*

*Details and a video demonstration for using PWRcrimp
Tool with Powerpole®s, go to:
www.westmountainradio.com/crimptool
www.westmountainradio.com/videos*

Specifications

Overall dimensions (maximum, w/o cables)	1.4" H x 11.75" W x 3.0" D
Weight	0.95 lb
Maximum total current	80 amps
Maximum single individual outlet current	40 amps (fuse protected)
ICAS current rating (fuse limited)	74 amps
Precision comparator window points	11.5, 15.0 Volts
Metering accuracy	better than 2% @ 25 deg.C.
Audible alert SPL output	~60dB SPL @ 1 meter
Reverse polarity protection (meter circuit)	Yes

RIGrunner Warranty

The RIGrunner is warranted against failure due to defects in workmanship or materials for one year after the date of purchase from West Mountain Radio or an authorized dealer. If purchased from an authorized dealer it must be returned with a copy of the original sales receipt or proof of purchase.

Warranty does not cover damage caused by abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation, alteration, lightning, or other incidence of excessive voltage or current. If failure occurs within this period, return the RIGrunner or accessory to West Mountain Radio at your shipping expense with a full explanation and necessary proof of purchase. The device or accessory will be repaired or replaced, at our option, without charge, and returned to you at our shipping expense. Repaired or replaced items are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the RIGrunner or accessory made after the expiration of the warranty period.

West Mountain Radio shall have no liability or responsibility to customer or any other person or entity with respect to any liability, loss, or damage caused directly or indirectly by use or performance of the products or arising out of any breach of this warranty, including, but not limited to, any damages resulting from inconvenience, loss of time, data, property, revenue, or profit, or any indirect, special incidental, or consequential damages, even if West Mountain Radio has been advised of such damages.

Except as provided herein, West Mountain Radio makes no express warranties and any implied warranties, including fitness for a particular purpose, are limited in duration to the stated duration provided herein.